



212 Avenida Fabricante
San Clemente, CA 92672
(949) 492 - 7777

TRUFIG and the TRUFIG Logo
are trademarks of Dana Innovations. © 2012 Dana Innovations. All rights reserved.

APPLICATION NOTE

G-03

Fabric and Wallpaper Install

Overview:

This application note will give instructions on how to install a TRUFIG mounting platform in a fabric or wallpaper application. All fabric installs use the same process, however wallpaper may require a different process depending on the physical characteristics of the wallpaper material. For thicker, pliable wallpapers, the install process will follow the fabric install process. For all other wallpaper applications use the specific wallpaper application outlined below. NOTE: a mock-up is strongly recommended for all wallpaper and fabric applications. This app note should serve only as a guide.

Below are detailed instructions and required materials for both applications.

Fabric Install

TRUFIG parts needed:

-TRUFIG Solid Surface Mounting Platform, trim component, & fascia (any size)

Installation Instructions:

Install the solid surface mounting platform into a rigid, smooth piece of material - like MDF. This material should be at least 1/2" thick, and at least 6" larger than the fascia opening of the device your installing. Use either the TRUFIG router templates, or a CNC machine to cut a precise fascia opening. See the TRUFIG Install Guide for more details on a solid surface install.

Once the mounting platform is installed and fastened onto the wall, install the fabric over the platform keeping note of the approximate location. See below details on how to finish the install.



Using sharp scissors, cut an "x" from the corners of the TRUFIG opening.



Use a small artist paint brush and apply an adhesive that is safe for the upholstery around the inside of the opening.



Next, use a putty knife, or similar, to tuck the fabric between the outside of the enclosure box and the MDF.



212 Avenida Fabricante
San Clemente, CA 92672
(949) 492 - 7777

TRUFIG and the TRUFIG Logo
are trademarks of Dana In-
novations. © 2012 Dana In-
novations. All rights reserved.

APPLICATION NOTE

G-03



Once finished tucking the fabric, the fabric around the opening should be even and tight.

Next, level the trim component and install the fascia.

Wallpaper Install

TRUFIG parts needed:

-TRUFIG Gypsum Mounting Platform, trim component, & fascia (any size)

Installation Instructions:

Install the gypsum mounting platform as instructed in the TRUFIG Install Guide. When it comes time to apply the wallpaper, be sure to apply extra paste or adhesive around the perimeter of the TRUFIG openings. Once the paper is dry, carefully and neatly trim the excess paper around the opening. If wallpaper is desired on the fascia, it can be applied directly to the surface of the fascia using wallpaper paste or adhesive. Wallpaper adhered to the over TRUFIG receptacle fascia (50401) is not recommended due to wallpaper becoming a fire hazard.